

Installation Instructions

03-0220 SpeedyMoto Ducati Monster
1-1/8" handlebar Risers and Top Cap
Fits 2002 - current S4R, S2R

Parts included

1. Two SpeedyMoto 1-1/8" risers
2. One SpeedyMoto 1-1/8" top cap
3. Four polished SpeedyMoto M8 x 100 mm bolts

Tools required

1. 6 mm Allen wrench
2. Dead-blow mallet
3. Torque wrench

Installation

1. Remove the 4 stock bolts from the stock bar clamps.
2. Replace the stock risers, top bar clamp, and bolts with the SpeedyMoto units.
3. Slightly tighten bar clamp bolts, in a crisscross pattern.
4. Use the factory handlebar marks to center, and adjust to your usual riding position.
5. Once satisfied with handlebar position, torque bar clamp bolts to 20 Nm (~15 Ft. Lbs.), in a crisscross pattern.
6. Lightly tap the center of the top bar clamp with a dead-blow mallet, to alleviate any uneven tension during the initial torquing.
7. Torque bar clamp bolts again, to 20 Nm (~15 Ft. Lbs.), in a crisscross pattern.
8. Do a preflight check: Turn the handlebars to extreme left, then right while twisting the throttle. Make sure that the throttle freely rotates from stop to stop. Also make sure of proper cable slack.
9. Ride it, and tell all your friends about SpeedyMoto!

6